

BS2_GetStatusConfig 1
..... 1
..... 1
..... 1

BS2_GetStatusConfig

LED, buzzer 가 .

```
#include "BS_API.h"

int BS2_GetStatusConfig(void* context, uint32_t deviceId, BS2StatusConfig* config);
```

BS2StatusConfig

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* : led, buzzer

BS_SDK_SUCCESS , 가

From:
<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getstatusconfig

Last update: **2017/06/28 11:24**