_BS2_GetUserInfosEx_ 1

BS2_GetUserInfosEx

.

```
#include "BS_API.h"

int BS2_GetUserInfosEx(void* context, uint32_t deviceId, char* uids,
uint32_t uidCount, BS2UserBlobEx* userBlob);
```

> BS2UserBlobEx

- [In] *context* : Context
- [In] *deviceId* :
- [In] *uids* :
- [In] *uidCount* :
- [Out] *userBlob* :

BS_SDK_SUCCESS ,

.

BS2_GetUserList
BS2_RemoveUser
BS2_RemoveAllUser
BS2_GetUserInfos
BS2_GetUserInfosEx
BS2_EnrolUser
BS2_EnrolUserEx
BS2_GetUserDatas
BS2_GetUserDatasEx

From:
<https://kb.supremainc.com/bs2sdk/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getuserinfosex&rev=1540949540

Last update: **2018/10/31 10:32**