

BS2_RemoveAllDeviceZone 1
 1
 1
 1
 1
 1

BS2_RemoveAllDeviceZone

Ethernet .


BioStation 2 (1.5.0 only)
BioStation A2 (1.4.0 only)
BioEntry P2 (1.0.0 only)

```
#include "BS_API.h"  
  
int BS2_RemoveAllDeviceZone(void* context, uint32_t deviceId);
```

- [In] *context* : Context
- [In] *deviceId* :

BS_SDK_SUCCESS , 가

- [BS2_GetDeviceZone](#)
- [BS2_GetAllDeviceZone](#)
- [BS2_SetDeviceZone](#)
- [BS2_RemoveDeviceZone](#)
- [BS2_SetIntrusionAlarmZoneAlarm](#)
- [BS2_SetDeviceZoneAlarm](#)



From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_removealldevicezone

Last update: **2018/03/22 10:50**