Configuration API > BS2_SetRelayActionConfig

BS2_SetRelayActionConfig

[+ 2.8.1] IM-120 RelayAction .

```
#include "BS_API.h"

int BS2_SetRelayActionConfig(void* context, uint32_t deviceId, const
BS2RelayActionConfig* config);
```

BS2RelayActionConfig

- [In] *context* : Context
- [In] *deviceId* :
- [In] *config* : RelayAction

BS_SDK_SUCCESS ,

.

From:
http://kb.supremainc.com/bs2sdk./ - **BioStar Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_setrelayactionconfig

Last update: **2021/08/05 10:31**