

Table of Contents

<i>BS2_GetAuthConfig</i>	1
Declaration	1
Parameter	1
Return Value	1

Configuration API > BS2_GetAuthConfig

BS2_GetAuthConfig

Retrieves authentication settings on the device

Declaration

```
#include "BS_API.h"

int BS2_GetAuthConfig(void* context, uint32_t deviceId, BS2AuthConfig*
config);
```

See BS2AuthConfig Structure

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *config* : Authentication configurations pointer

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.

If there is an error, the corresponding error code will be returned.

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2_getauthconfig

Last update: **2016/07/12 09:10**