

BS2_GetRelayActionConfig	1
	1
	1
	1

Configuration API > BS2_GetRelayActionConfig

BS2_GetRelayActionConfig

[+ 2.8.1] IM-120 RelayAction 가 .

```
#include "BS_API.h"

int BS2_GetRelayActionConfig(void* context, uint32_t deviceId,
BS2RelayActionConfig* config);
```

BS2RelayActionConfig

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* : RelayAction

BS_SDK_SUCCESS , 가

From:

<http://kb.supremainc.com/bs2sdk/> - BioStar 2 Device SDK

Permanent link:

http://kb.supremainc.com/bs2sdk/doku.php?id=ko:bs2_getrelayactionconfig

Last update: 2021/08/05 10:31