

<b>BS2_SetGlobalAPBViolationByDoorOpenHandler</b>	.....	1
.....	.....	1
.....	.....	1
.....	.....	1
.....	.....	2

## [Zone Control API](#) > [BS2\\_SetGlobalAPBViolationByDoorOpenHandler](#)

## **BS2\_SetGlobalAPBViolationByDoorOpenHandler**

[ + 2.7.0] 가  
Global APB(BS2\_SetCheckGlobalAPBViolationHandler )가  
Global APB By Door Open , 2  
1 가 , OnCheckGlobalAPBViolationByDoorOpen  
2 , 가  
OnUpdateGlobalAPBViolationByDoorOpen  
OnUpdateGlobalAPBViolationByDoorOpen update

```
#include "BS_API.h"

int BS2_SetGlobalAPBViolationByDoorOpenHandler(void* context,
OnCheckGlobalAPBViolationByDoorOpen ptrCheck,
OnUpdateGlobalAPBViolationByDoorOpen ptrUpdate);
```

**OnCheckGlobalAPBViolationByDoorOpen**  
**OnUpdateGlobalAPBViolationByDoorOpen**

- [In] *context* : Context
  - [In] *ptrCheck* :
  - [In] *ptrUpdate* :

BS2AuthConfig useGlobalAPB가 true ,  
BS2DoorSensor apbUseDoorSensor가 true

BS SDK SUCCESS , 가

## BS2\_CheckGlobalAPBViolationByDoorOpen

From:

<https://kb.supremainc.com/bs2sdk./> - **BioStar 2 Device SDK**

Permanent link:

[https://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2\\_setglobalapbviolationbydooropenhandler&rev=1595331057](https://kb.supremainc.com/bs2sdk./doku.php?id=ko:bs2_setglobalapbviolationbydooropenhandler&rev=1595331057)

Last update: **2020/07/21 20:30**