

Table of Contents

BS2_AllocateUsbContext	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[USB Exported Control API](#) > [BS2_AllocateUsbContext](#)

BS2_AllocateUsbContext

[Deprecated][+ 2.5.0] Allocates context which manages & controls USB device. Log and user data can be retrieved from USB device through the USB context.

Declaration

```
#include "BS_API.h"

void* BS2_AllocateUsbContext(const char* szDir);
```

Parameter

- [In] *szDir* : USB device directory

NOTE

The logsObj variable needs to return the memory to the system by the BS2_ReleaseObject function after being used.

Return Value

Returns NULL when there is not enough system memory, if not, returns the allocated Context.

See Also

[BS2_ReleaseUsbContext](#)
[BS2_GetUserDatabaseInfoFromDir](#)
[BS2_GetUserListFromDir](#)
[BS2_GetUserInfosFromDir](#)
[BS2_GetUserDatasFromDir](#)
[BS2_GetUserInfosExFromDir](#)
[BS2_GetUserDatasExFromDir](#)
[BS2_GetLogFromDir](#)
[BS2_GetLogBlobFromDir](#)
[BS2_GetFilteredLogFromDir](#)

From:
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_allocateusbcontext

Last update: **2022/04/22 12:20**