

Table of Contents

BS2_GetAllTimedAntiPassbackZoneStatus	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Zone Control API](#) > [BS2_GetAllTimedAntiPassbackZoneStatus](#)

BS2_GetAllTimedAntiPassbackZoneStatus

Retrieves the status of all timed Anti Passback zones.

Declaration

```
#include "BS_API.h"

int BS2_GetAllTimedAntiPassbackZoneStatus(void* context, uint32_t deviceId,
BS2ZoneStatus** zoneStatusObj, uint32_t* numZoneStatus);
```

[See BS2ZoneStatus Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *zoneStatusObj* : Zone status list pointer
- [Out] *numZoneStatus* : Number of zone status records

NOTE

The *zoneStatusObj* variable needs to return the memory to the system by the [BS2_ReleaseObject](#) function after being used.

Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetTimedAntiPassbackZone](#)
[BS2_GetAllTimedAntiPassbackZone](#)
[BS2_GetTimedAntiPassbackZoneStatus](#)
[BS2_SetTimedAntiPassbackZone](#)

[BS2_SetTimedAntiPassbackZoneAlarm](#)
[BS2_RemoveTimedAntiPassbackZone](#)
[BS2_RemoveAllTimedAntiPassbackZone](#)
[BS2_ClearTimedAntiPassbackZoneStatus](#)
[BS2_ClearAllTimedAntiPassbackZoneStatus](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_getalltimedantipassbackzonestatus

Last update: **2016/07/12 10:04**