

# Table of Contents

<b>BS2_GetInputConfigEx</b> .....	1
API .....	1
Parameters .....	1
Return Values .....	1

[Configuration API](#) > [BS2\\_GetInputConfigEx](#)

---

## BS2\_GetInputConfigEx

[+ 2.8.1] IM-120 Retrieves Input Expandable Settings.

### API

```
#include "BS_API.h"

int BS2_GetInputConfigEx(void* context, uint32_t deviceId, BS2InputConfigEx* config);
```

[BS2InputConfigEx Structure](#)

### Parameters

- [In] *context* : Context
- [In] *deviceId* : Device Identifier
- [Out] *config* : Pointer where Input Expandable Setting Information will be saved

### Return Values

Return `BS_SDK_SUCCESS` when successful, and return an appropriate error code when an error occurs.

From:  
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:  
[https://kb.supremainc.com/kbtest/doku.php?id=en:bs2\\_getinputconfigex&rev=1628205218](https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_getinputconfigex&rev=1628205218)

Last update: **2021/08/06 08:13**