

Table of Contents

BS2_GetSystemExtConfig	1
Declaration	1
Parameter	1
Return Value	1

[Configuration API](#) > [BS2_GetSystemExtConfig](#)

BS2_GetSystemExtConfig

Retrieves Master and slave device encryption settings from the device.

IMPORTANT

You are not able to retrieve a key value due to security reason.

Declaration

```
#include "BS_API.h"

int BS2_GetSystemExtConfig(void* context, uint32_t deviceId,
BS2SystemConfigExt* config);
```

[See BS2SystemConfigExt Structure](#)

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [Out] *config* : Master and slave device encryption settings pointer

Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.
If there is an error, the corresponding error code will be returned.

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_getsystemextconfig&rev=1581987193

Last update: **2020/02/18 09:53**