

Table of Contents

BS2_GetUserInfosExFromDir

Declaration

Parameter

Return Value

See Also

..... 1

..... 1

..... 1

..... 1

..... 1

BS2_GetUserInfosExFromDir

Gets the user information of the given user ID.

Declaration

```
#include "BS_API.h"

int BS2_GetUserInfosExFromDir(void* context, const char* szDir, char* uids,
uint32_t uidCount, BS2UserBlobEx* userBlob);
```

[See BS2UserBlobEx Structure](#)

Parameter

- [In] *context* : Context
- [In] *szDir* : Storage path in device
- [In] *uids* : User ID list trying to get
- [In] *uidCount* : Number of user ID
- [Out] *userBlob* : Pointer to store the user information

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetUserListFromDir](#)

[BS2_GetUserInfosFromDir](#)

From:
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_getuserinfosexfromdir&rev=1504600615

Last update: **2017/09/05 17:36**