

Table of Contents

BS2_GetUserInfosFaceExFromDir

Declaration

Parameters

Return value

See Also

1

1

1

1

1

[USB Exported Control API](#) > [BS2_GetUserInfosFaceExFromDir](#)

BS2_GetUserInfosFaceExFromDir

[+2.7.1] Gets the user information corresponding to the user identifier from the data extracted by USB. Supports USB files exported from FaceStation F2 devices.

Declaration

```
#include "BS_API.h"

int BS2_GetUserInfosFaceExFromDir(void* context, const char* szDir, char*
uids, uint32_t uidCount, BS2UserFaceExBlob* userBlob);
```

[View the structure of the BS2UserFaceExBlob](#)

Parameters

- [In] *context* : Context
- [In] *szDir* : Data storage path
- [In] *uids* : List of user identifiers to be imported
- [In] *uidCount* : Number of user identifiers
- [Out] *userBlob* : Pointer to store user information

Return value

Returns BS_SDK_SUCCESS if performed successfully, or a corresponding error code if an error occurs.

See Also

[BS2_GetUserDatasFaceExFromDir](#)

From:
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_getuserinfosfaceexfromdir

Last update: **2022/04/21 10:36**

