Table of Contents

USB Exported Control API > BS2_GetUserSmallInfosFromDirWithKey

BS2_GetUserSmallInfosFromDirWithKey

[+2.8.2] Gets the user information corresponding to the user identifier from the data extracted by USB.
BS2UserBlob The difference from BS2_GetUserInfosFromDirWithKey is
For memory efficiency, all are the same except that the fifth factor BS2UserSmallBlob member BS2UserPhoto is pointer-processed.

Declaration

```
#include "BS_API.h"

int BS2_GetUserSmallInfosFromDirWithKey(void* context, const char* szDir,
char* uids, uint32_t uidCount, BS2UserSmallBlob* userBlob, const
BS2EncryptKey* key);
```

> View the structure of the BS2UserSmallBlob

Parameters

- [In] *context* : Context
- [In] *szDir* : Data storage path
- [In] *uids* : List of user identifiers to be imported
- [In] *uidCount* : Number of user identifiers
- [Out] *userBlob* : Pointer to store user information
- [In] *key* : Encryption key and the key value specified by BS2_SetDataEncryptKey

Return value

Returns BS_SDK_SUCCESS if performed successfully, or a corresponding error code if an error occurs.

See Also

BS2_GetUserSmallInfosFromDirWithKey
BS2_GetUserSmallDatasFromDirWithKey
BS2_GetUserSmallInfosExFromDirWithKey
BS2_GetUserSmallDatasExFromDirWithKey

From:
http://kb.supremainc.com/bs2sdk/ - **BioStar 2 Device SDK**

Permanent link:
http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_getusersmallinfosfromdirwithkey

Last update: **2022/04/21 09:50**