

Table of Contents

BS2_IsAutoConnection	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Communication API](#) > [BS2_IsAutoConnection](#)

BS2_IsAutoConnection

Check whether automatic connection is configured.

If auto-connect is enabled, it automatically calls the connected callback function specified in [BS2_SetDeviceEventListener](#) after the socket connection from the device is accepted.

Declaration

```
#include "BS_API.h"

int BS2_IsAutoConnection(void* context, int* enable);
```

Parameter

- [In] *context* : Context
- [Out] *enable* : Whether auto connection is enabled

Return Value

If successfully done, BS_SDK_SUCCESS will be returned. If there is an error, the corresponding error code will be returned.

See Also

[BS2_SetAutoConnection](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

http://kb.supremainc.com/bs2sdk./doku.php?id=en:bs2_isautoconnection

Last update: **2018/11/02 12:17**