

Table of Contents

BS2_ReleaseContext	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[SDK API](#) > [BS2_ReleaseContext](#)

BS2_ReleaseContext

Releases the context allocated from the `BS2_AllocateContext()` function. If the pointer value is NULL, it doesn't do any action.

NOTE

Use this if the context is not used anymore. We strongly recommend you to call this API only once when the application ends.

Declaration

```
#include "BS_API.h"

void BS2_ReleaseContext(void* context);
```

Parameter

- [In] *context* : Context

Return Value

Void

See Also

[BS2_AllocateContext](#)

From: <https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link: https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_releasecontext

Last update: **2019/02/22 12:14**