

Table of Contents

BS2_RemoveDeviceZoneMasterConfig	1
Supported devices	1
Declaration	1
Parameter	1
Return Value	1
See Also	1

[Zone Control API](#) > [BS2_RemoveDeviceZoneMasterConfig](#)

BS2_RemoveDeviceZoneMasterConfig

Removes the zone master config of the Ethernet zone.

Supported devices

BioStation 2 (1.5.0 only)
BioStatioin A2 (1.4.0 only)
BioEntry P2 (1.0.0 only)

Declaration

```
#include "BS_API.h"

int BS2_RemoveDeviceZoneMasterConfig(void* context, BS2_DEVICE_ID deviceId);
```

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID

Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.
If there is an error, the corresponding error code will be returned.

See Also

[BS2_GetDeviceZoneMasterConfig](#)
[BS2_SetDeviceZoneMasterConfig](#)

From:
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_removedevicezonemasterconfig

Last update: **2021/01/06 15:09**