

Table of Contents

BS2_RunAction	1
Declaration	1
Parameters	1
Return Values	1

[Device API](#) > [BS2_RunAction](#)

BS2_RunAction

[+ 2.8.1] Commands the device to take certain actions.
Using this API, you can control LED, buzzer, sound, relay and more.

Declaration

```
#include "BS_API.h"

int BS2_RunAction(void* context, uint32_t deviceId, const BS2Action*
action);
```

[BS2Action Structure](#)

Parameters

- [In] *context* : Context
- [In] *deviceId* : Device Identifier
- [In] *action* : Structure address where certain actions are defined

Return Values

Return `BS_SDK_SUCCESS` when successful, and return an appropriate error code when an error occurs.

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_runaction

Last update: **2021/08/06 15:50**