

# Table of Contents

|  |   |
|--|---|
| <b>BS2_SetAccessGroupEntranceLimit</b> ..... | 1 |
| Supported devices .....                      | 1 |
| Declaration .....                            | 1 |
| Parameter .....                              | 1 |
| Return Value .....                           | 1 |
| See Also .....                               | 1 |

## BS2\_SetAccessGroupEntranceLimit

Configures access group entrance limit.

### Supported devices

BioStation 2 (1.5.0 only)  
BioStatioin A2 (1.4.0 only)  
BioEntry P2 (1.0.0 only)

### Declaration

```
#include "BS_API.h"

int BS2_SetAccessGroupEntranceLimit(void* context, BS2_DEVICE_ID deviceId,
const BS2DeviceZoneAGEntranceLimit* agEntranceLimits, uint32_t
agEntranceLimitCount);
```

[See BS2DeviceZoneAGEntranceLimit Structure](#)

### Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *agEntranceLimits* : Device zone access group entrance limit list
- [In] *agEntranceLimitCount* : Number of device zone access group entrance limit list

### Return Value

If successfully done, `BS_SDK_SUCCESS` will be returned.  
If there is an error, the corresponding error code will be returned.

### See Also

[BS2\\_GetAccessGroupEntranceLimit](#)  
[BS2\\_GetAllAccessGroupEntranceLimit](#)  
[BS2\\_RemoveAccessGroupEntranceLimit](#)

## BS2\_RemoveAllAccessGroupEntranceLimit

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

[https://kb.supremainc.com/kbtest/doku.php?id=en:bs2\\_setaccessgroupentrancelimit&rev=1521683862](https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_setaccessgroupentrancelimit&rev=1521683862)

Last update: **2018/03/22 10:57**