

# Table of Contents

<b>BS2_SetCheckGlobalAPBViolationHandler</b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1
See Also .....	1

[Zone Control API](#) > [BS2\\_SetCheckGlobalAPBViolationHandler](#)

---

## BS2\_SetCheckGlobalAPBViolationHandler

[+ 2.5.0] Registers callback function for global determination when an APB violation alarm occurs.

### Declaration

```
#include "BS_API.h"

int BS2_SetCheckGlobalAPBViolationHandler(void* context,
OnCheckGlobalAPBViolation ptrCheckGlobalAPBViolation);
```

See [OnCheckGlobalAPBViolation](#) callback function

### Parameter

- [In] *context* : Context
- [In] *ptrCheckGlobalAPBViolation* : Callback function called for global determination when Anti Passback alarm occurs

#### NOTE

To use Global Anti Passback service, [BS2AuthConfig](#) useGloable APB should be set to True.

### Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned.  
If there is an error, the corresponding error code will be returned.

### See Also

[BS2\\_CheckGlobalAPBViolation](#)

From:

<http://kb.supremainc.com/bs2sdk/> - **BioStar 2 Device SDK**

Permanent link:

[http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2\\_setcheckglobalapbviolationhandler](http://kb.supremainc.com/bs2sdk/doku.php?id=en:bs2_setcheckglobalapbviolationhandler)

Last update: **2018/03/29 08:54**