# Table of Contents

***BS2_SetRS485ConfigExDynamic*** ..... 1
Declaration ..... 1
Parameter ..... 1
Return Value ..... 1
See Also ..... 1

# BS2_SetRS485ConfigExDynamic

[+ 2.9.9] Saves the RS485 network setting information for CoreStation.

## Declaration

```
#include "BS_API.h"

int BS2_SetRS485ConfigExDynamic(void* context, uint32_t deviceId,
BS2Rs485ConfigEXDynamic* config);
```

> Supported Devices: CoreStation 20(CS-20, CS-20P), Door Interface(DI-24)

> See BS2Rs485ConfigEXDynamic Structure

## Parameter

- [In] *context* : Context
- [In] *deviceId* : Device Identifier
- [Out] *config* : Pointer to store RS485 network setting information

## Return Value

If successfully done, BS_SDK_SUCCESS will be returned. If there is an error, the corresponding error code will be returned.

## See Also

BS2_GetRS485ConfigExDynamic

From:
https://kb.supremainc.com/kbtest/ - **BioStar Device SDK**

Permanent link:
**https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_setrs485configexdynamic**

Last update: **2025/06/12 10:23**