

# Table of Contents

<b>BS2_SetStatusConfig</b> .....	1
Declaration .....	1
Parameter .....	1
Return Value .....	1

[Configuration API](#) > [BS2\\_SetStatusConfig](#)

---

## BS2\_SetStatusConfig

Stores LED and buzzer settings on the device.

### Declaration

```
#include "BS_API.h"

int BS2_SetStatusConfig(void* context, uint32_t deviceId, BS2StatusConfig* config);
```

[See BS2StatusConfig Structure](#)

### Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *config* : LED, buzzer configurations pointer

### Return Value

If successfully done, BS\_SDK\_SUCCESS will be returned.  
If there is an error, the corresponding error code will be returned.

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

[https://kb.supremainc.com/kbtest/doku.php?id=en:bs2\\_setstatusconfig](https://kb.supremainc.com/kbtest/doku.php?id=en:bs2_setstatusconfig)

Last update: **2016/07/12 09:31**