Table of Contents

BS2_SetThermalCameraConfig

[+ 2.7.1] FaceStation F2, FaceStation2 Stores configuration of thermal camera.

Declaration

```
#include "BS_API.h"

int BS2_SetThermalCameraConfig(void* context, uint32_t deviceId, const
BS2ThermalCameraConfig* config);
```

See BS2ThermalCameraConfig Structure

Parameter

- [In] *context* : Context
- [In] *deviceId* : Device ID
- [In] *config* : Thermal camera settings pointer

Return Value

If successfully done, BS_SDK_SUCCESS will be returned.
If there is an error, the corresponding error code will be returned.