BS2_CheckGlobalAPBViolationByDoorOpen

Zone Control API > BS2_CheckGlobalAPBViolationByDoorOpen

BS2_CheckGlobalAPBViolationByDoorOpen

[+ 2.7.0]

```
#include "BS_API.h"

int BS2_CheckGlobalAPBViolationByDoorOpen(void* context, uint32_t deviceId,
uint16_t seq, int handleResult, uint32_t zoneID);
```

- [In] *context* : Context
- [In] *deviceId* :
- [In] *seq* :
- [In] *handleResult* :   (BS_SDK_SUCCESS or
  BS_SDK_ERROR_XXX)
- [In] *zoneID* :   id

> OnCheckGlobalAPBViolationByDoorOpen
>   .

BS_SDK_SUCCESS   ,
      .

BS2_SetGlobalAPBViolationByDoorOpenHandler

From:

https://kb.supremainc.com/kbtest/ - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_checkglobalapbviolationbydoor open

Last update: **2020/07/21 20:33**