

**BS2\_GetDesFireCardConfigEx** ..... 1

..... 1

..... 1

..... 1

..... 1

# BS2\_GetDesFireCardConfigEx

[+ V2.6.4] DesFire 가 .

```
#include "BS_API.h"

int BS2_GetDesFireCardConfigEx(void* context, uint32_t deviceId,
BS2DesFireCardConfigEx* config);
```

BS2DesFireCardConfigEx

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* : DesFire

BS\_SDK\_SUCCESS , 가

## BS2\_SetDesFireCardConfigEx

From:  
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:  
[https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2\\_getdesfirecardconfigex&rev=1581925744](https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getdesfirecardconfigex&rev=1581925744)

Last update: **2020/02/17 16:49**