

BS2_GetDeviceZone 1

..... 1

..... 1

..... 1

..... 1

..... 2

BS2_GetDeviceZone

Ethernet 가 .

BioStation 2 (1.5.0) BioStatioin A2 (1.4.0) BioEntry P2 (1.0.0

```
#include "BS_API.h"

int BS2_GetDeviceZone(void* context, BS2_DEVICE_ID deviceId, const
BS2_DEVICE_ZONE_TABLE_ID* Ids, uint32_t IdCount, BS2DeviceZone**
deviceZoneObj, uint32_t* numDeviceZone);
```

BS2DeviceZone

- [In] *context* : Context
- [In] *deviceId* :
- [In] *Ids* : 가 device zone id
- [In] *IdCount* : device zone id
- [Out] *deviceZoneObj* : device zone
- [Out] *numDeviceZone* : device zone



BS_SDK_SUCCESS , 가

[BS2_GetAllDeviceZone](#)
[BS2_SetDeviceZone](#)
[BS2_RemoveDeviceZone](#)
[BS2_RemoveAllDeviceZone](#)
[BS2_SetDeviceZoneAlarm](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getdevicezone&rev=1521683087

Last update: **2018/03/22 10:44**