

**BS2\_GetDeviceZone** ..... 1

..... 1

..... 1

..... 1

..... 1

..... 2

# BS2\_GetDeviceZone

Ethernet 가 .

BioStation 2 (1.5.0 )  
BioStation A2 (1.4.0 )  
BioEntry P2 (1.0.0 )

```
#include "BS_API.h"

int BS2_GetDeviceZone(void* context, BS2_DEVICE_ID deviceId, const
BS2_DEVICE_ZONE_TABLE_ID* Ids, uint32_t IdCount, BS2DeviceZone**
deviceZoneObj, uint32_t* numDeviceZone);
```

## BS2DeviceZone

- [In] *context* : Context
- [In] *deviceId* :
- [In] *Ids* : 가 device zone id
- [In] *IdCount* : device zone id
- [Out] *deviceZoneObj* : device zone
- [Out] *numDeviceZone* : device zone

zoneObj                      [BS2\\_ReleaseObject](#)

BS\_SDK\_SUCCESS , 가

BS2\_GetAllDeviceZone  
BS2\_SetDeviceZone  
BS2\_RemoveDeviceZone  
BS2\_RemoveAllDeviceZone  
BS2\_SetDeviceZoneAlarm

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

[https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2\\_getdevicezone&rev=1521683102](https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getdevicezone&rev=1521683102)

Last update: **2018/03/22 10:45**