

BS2_GetOsdpStandardDeviceCapability 1

..... 1

..... 1

..... 1

..... 1

(C++) 1

(C#) 2

BS2_GetOsdpStandardDeviceCapability

[+ 2.8.4] CoreStation40 OSDP 가 .

```
#include "BS_API.h"

int BS2_GetOsdpStandardDeviceCapability(void* context, uint32_t
osdpDeviceId, BS2OsdpStandardDeviceCapability* capability);
```

[BS2OsdpStandardDeviceCapability](#)

- [In] *context* : Context
- [In] *osdpDeviceId* : OSDP
- [Out] *capability* :

BS_SDK_SUCCESS , 가

- [BS2_AddOsdpStandardDevice](#)
- [BS2_GetOsdpStandardDevice](#)
- [BS2_GetAvailableOsdpStandardDevice](#)
- [BS2_UpdateOsdpStandardDevice](#)
- [BS2_RemoveOsdpStandardDevice](#)
- [BS2_GetOsdpStandardDeviceCapability](#)
- [BS2_SetOsdpStandardDeviceSecurityKey](#)

(C++)

[sample_bs2_getosdpstandarddevicecapability.cpp](#)

```
BS2osdpStandardDeviceCapability capability = { , };

BS2_DEVICE_ID id = Utility::selectSlaveID();
int sdkResult = BS2_GetOsdpStandardDeviceCapability(context_, id,
&capability);
if (BS_SDK_SUCCESS != sdkResult)
    printf("BS2_GetOsdpStandardDeviceCapability call failed: %d",
sdkResult);

return sdkResult;
```

(C#)

[sample_bs2_getosdpstandarddevicecapability.cs](#)

```
UInt32 id = Util.GetInputSlaveID();

BS2osdpStandardDeviceCapability capability;
BS2ErrorCode result =
(BS2ErrorCode)API.BS2_GetOsdpStandardDeviceCapability(sdkContext, id,
out capability);
if (result != BS2ErrorCode.BS_SDK_SUCCESS)
    Console.WriteLine("Got error({0}).", result);
else
    Console.WriteLine("Call success.");

return result;
```

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getosdpstandarddevicecapability&rev=1675928190

Last update: **2023/02/09 16:36**