

BS2_GetRS485ConfigExDynamic 1
..... 1
..... 1
..... 1
..... 1

BS2_GetRS485ConfigExDynamic

[+ 2.9.9] CoreStation RS485 가 .

```
#include "BS_API.h"
```

```
int BS2_GetRS485ConfigExDynamic(void* context, uint32_t deviceId,
BS2Rs485ConfigEXDynamic* config);
```

: CoreStation 20(CS-20, CS-20P), Door Interface(DI-24)

BS2FacilityCodeConfig

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* : BS2FacilityCodeConfig

BS_SDK_SUCCESS , 가

BS2_SetFacilityCodeConfig

From: <https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link: https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getrs485configexdynamic&rev=1749618079

Last update: **2025/06/11 14:01**