

**BS2\_GetTNAConfig** ..... 1  
..... 1  
..... 1  
..... 1

# BS2\_GetTNAConfig

T&A 가 .

```
#include "BS_API.h"

int BS2_GetTNAConfig(void* context, uint32_t deviceId, BS2TNAConfig* config);
```

BS2TNAConfig

- [In] *context* : Context
- [In] *deviceId* :
- [Out] *config* : TNA

BS\_SDK\_SUCCESS , 가

From: <https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link: [https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2\\_gettnaconfig](https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_gettnaconfig)

Last update: **2016/07/12 09:33**