

**BS2\_GetUserDatasExFromDir** .....

.....

.....

.....

.....

.....

1

1

1

1

1

1

# BS2\_GetUserDatasExFromDir

Usb                      Data                                              가                      .

```
#include "BS_API.h"

int BS2_GetUserDatasExFromDir(void* context, const char* szDir, char* uids,
uint32_t uidCount, BS2UserBlobEx* userBlob, BS2_USER_MASK userMask);
```

BS2UserBlobEx

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :
- [In] *userMask* :                      Mask

BS\_SDK\_SUCCESS                      ,                      가

- BS2\_AllocateUsbContext
- BS2\_ReleaseUsbContext
- BS2\_GetUserDatabaseInfoFromDir
- BS2\_GetUserListFromDir
- BS2\_GetUserInfosFromDir
- BS2\_GetUserDatasFromDir
- BS2\_GetUserInfosExFromDir
- BS2\_GetLogFromDir
- BS2\_GetLogBlobFromDir
- BS2\_GetFilteredLogFromDir

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

[https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2\\_getuserdatasexfromdir&rev=1540861403](https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getuserdatasexfromdir&rev=1540861403)

Last update: **2018/10/30 10:03**