

BS2_GetUserDatasFaceExFromDir 1
..... 1
..... 1
..... 2
..... 2

BS2_GetUserDatasFaceExFromDir

[+2.7.1] USB Data 가 .
FaceStaion F2 export USB file .

```
#include "BS_API.h"
```

```
int BS2_GetUserDatasFaceExFromDir(void* context, const char* szDir, char* uids, uint32_t uidCount, BS2UserFaceExBlob* userBlob, BS2_USER_MASK userMask);
```

BS2UserFaceExBlob

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :
- [In] *userMask* : Mask

0x0000	
0x0001	data
0x0002	
0x0004	
0x0008	
0x0010	PIN
0x0020	
0x0040	
0x0080	
0x0100	
0x0200	
0x0400	
0x0800	(FaceStation F2)
0x1000	(FaceStation F2)

0xFFFF	

BS_SDK_SUCCESS , 가

BS2_GetUserInfosFaceExFromDir

From:
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getuserdatasfaceexfromdir

Last update: **2022/04/12 14:15**