

**BS2\_GetUserInfosExFromDir** ..... 1  
..... 1  
..... 1  
..... 1  
..... 1

# BS2\_GetUserInfosExFromDir

[+ 2.5.0] Usb

Data

가

.

```
#include "BS_API.h"

int BS2_GetUserInfosExFromDir(void* context, const char* szDir, char* uids,
uint32_t uidCount, BS2UserBlobEx* userBlob);
```

[BS2UserBlobEx](#)

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :

BS\_SDK\_SUCCESS , 가

- [BS2\\_AllocateUsbContext](#)
- [BS2\\_ReleaseUsbContext](#)
- [BS2\\_GetUserDatabaseInfoFromDir](#)
- [BS2\\_GetUserListFromDir](#)
- [BS2\\_GetUserInfosFromDir](#)
- [BS2\\_GetUserDatasFromDir](#)
- [BS2\\_GetUserDatasExFromDir](#)
- [BS2\\_GetLogFromDir](#)
- [BS2\\_GetLogBlobFromDir](#)
- [BS2\\_GetFilteredLogFromDir](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

[https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2\\_getuserinfosexfromdir&rev=1540884074](https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getuserinfosexfromdir&rev=1540884074)

Last update: **2018/10/30 16:21**