

BS2_GetUserInfosFaceExFromDirWithKey 1
..... 1
..... 1
..... 1
..... 1

BS2_GetUserInfosFaceExFromDirWithKey

[+2.8.2] USB FaceStation F2 Data export USB file 가 .

```
#include "BS_API.h"


int BS2_GetUserInfosFaceExFromDirWithKey(void* context, const char* szDir,
char* uids, uint32_t uidCount, BS2UserFaceExBlob* userBlob, const
BS2EncryptKey* key);
```

BS2UserFaceExBlob

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :
- [In] *key* : [BS2_SetDataEncryptKey](#) .

BS_SDK_SUCCESS , 가

BS2_GetUserDatasFaceExFromDirWithKey



From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getuserinfosfaceexfromdirwithkey

Last update: **2022/04/12 15:37**