

BS2_GetUserInfosFromDir

.....

.....

.....

.....

.....

.....

1

1

1

1

1

User Management API > [BS2_GetUserInfosFromDir](#)

BS2_GetUserInfosFromDir

Usb Data 가 .

```
#include "BS_API.h"

int BS2_GetUserInfosFromDir(void* context, const char* szDir, char* uids,
uint32_t uidCount, BS2UserBlob* userBlob);
```

BS2UserBlob

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :

BS_SDK_SUCCESS , 가

[BS2_GetUserDatabaseInfoFromDir](#)

[BS2_GetUserListFromDir](#)

[BS2_GetUserDatasFromDir](#)

[BS2_GetUserInfosExFromDir](#)

[BS2_GetUserDatasExFromDir](#)

[BS2_GetLogFromDir](#)

[BS2_GetLogBlobFromDir](#)

[BS2_GetFilteredLogFromDir](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getuserinfosfromdir&rev=1540860953

Last update: **2018/10/30 09:55**