

BS2_GetUserInfosFromDir 1
..... 1
..... 1
..... 1
..... 1

BS2_GetUserInfosFromDir

[+ 2.5.0] Usb Data 가 .

```
#include "BS_API.h"

int BS2_GetUserInfosFromDir(void* context, const char* szDir, char* uids,
uint32_t uidCount, BS2UserBlob* userBlob);
```

BS2UserBlob

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :

BS_SDK_SUCCESS , 가

- BS2_AllocateUsbContext
- BS2_ReleaseUsbContext
- BS2_GetUserDatabaseInfoFromDir
- BS2_GetUserListFromDir
- BS2_GetUserDatasFromDir
- BS2_GetUserInfosExFromDir
- BS2_GetUserDatasExFromDir
- BS2_GetLogFromDir
- BS2_GetLogBlobFromDir
- BS2_GetFilteredLogFromDir

From:
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getuserinfosfromdir&rev=1540884051

Last update: **2018/10/30 16:20**