

BS2_GetUserInfosFromDirWithKey 1
..... 1
..... 1
..... 1
..... 1

USB Exported Control API > BS2_GetUserInfosFromDirWithKey

BS2_GetUserInfosFromDirWithKey

[+2.8.2] USB

Data

가

.

```
#include "BS_API.h"

int BS2_GetUserInfosFromDirWithKey(void* context, const char* szDir, char*
uids, uint32_t uidCount, BS2UserBlob* userBlob, const BS2EncryptKey* key);
```

BS2UserBlob

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :
- [In] *key* : [BS2_SetDataEncryptKey](#) .

BS_SDK_SUCCESS

, 가

- [BS2_GetUserDatabaseInfoFromDirWithKey](#)
- [BS2_GetUserListFromDirWithKey](#)
- [BS2_GetUserDatasesFromDirWithKey](#)
- [BS2_GetUserInfosExFromDirWithKey](#)
- [BS2_GetUserDatasesExFromDirWithKey](#)
- [BS2_GetLogFromDirWithKey](#)
- [BS2_GetLogBlobFromDirWithKey](#)
- [BS2_GetFilteredLogFromDirWithKey](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getuserinfosfromdirwithkey

Last update: **2022/04/12 15:26**