

BS2_GetUserListFromDir 1

..... 1

..... 1

..... 1

..... 1


BS2_GetUserListFromDir

Usb Data 가 .

```
#include "BS_API.h"

int BS2_GetUserListFromDir(void* context, const char* szDir, char** uidsObj,
uint32_t* numUid, IsAcceptableUserID ptrIsAcceptableUserID);
```

- [In] *context* : Context
- [Out] *szDir* : Data
- [Out] *uidsObjs* :
- [Out] *numUid* :
- [In] *ptrIsAcceptableUserID* : TBD



BS_SDK_SUCCESS , 가

- [BS2_GetUserDatabaseInfoFromDir](#)
- [BS2_GetUserInfosFromDir](#)
- [BS2_GetUserDatasFromDir](#)
- [BS2_GetUserInfosExFromDir](#)
- [BS2_GetUserDatasExFromDir](#)
- [BS2_GetLogFromDir](#)
- [BS2_GetLogBlobFromDir](#)
- [BS2_GetFilteredLogFromDir](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getuserlistfromdir&rev=1540860933

Last update: **2018/10/30 09:55**