

BS2_GetUserSmallDatasExFromDir

.....

.....

.....

.....

.....

.....

1

1

1

2

2

BS2_GetUserSmallDatasExFromDir

[+ 2.6.3] USB Data 가 .
BS2UserBlobEx BS2_GetUserDatasExFromDir
5 BS2UserSmallBlobEx BS2UserPhoto가

```
#include "BS_API.h"

int BS2_GetUserSmallDatasExFromDir(void* context, const char* szDir, char*
uids, uint32_t uidCount, BS2UserSmallBlobEx* userBlob, BS2_USER_MASK
userMask);
```

BS2UserSmallBlobEx

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :
- [In] *userMask* : Mask

0x0000	
0x0001	data
0x0002	
0x0004	
0x0008	
0x0010	PIN
0x0020	
0x0040	
0x0080	
0x0100	
0x0200	
0x0400	
0x0800	(FaceStation F2)

0x1000	(FaceStation F2)
0xFFFF	

BS_SDK_SUCCESS , 가

[BS2_GetUserSmallInfosFromDir](#)

[BS2_GetUserSmallDatasFromDir](#)

[BS2_GetUserSmallInfosExFromDir](#)

[BS2_GetUserSmallDatasExFromDir](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getusersmalldatasexfromdir

Last update: **2020/08/21 11:51**