

BS2_GetUserSmallInfosExFromDirWithKey

.....

.....

.....

.....

.....

.....

1

1

1

1

1

[USB Exported Control API](#) > [BS2_GetUserSmallInfosExFromDirWithKey](#)

BS2_GetUserSmallInfosExFromDirWithKey

[+2.8.2] USB Data 가 .
[BS2UserBlobEx](#) [BS2_GetUserInfosExFromDirWithKey](#)
5 BS2UserSmallBlobEx BS2UserPhoto가 .

```
#include "BS_API.h"
```

```
int BS2_GetUserSmallInfosExFromDirWithKey(void* context, const char* szDir,  
char* uids, uint32_t uidCount, BS2UserSmallBlobEx* userBlob, const  
BS2EncryptKey* key);
```

[BS2UserSmallBlobEx](#)

- [In] *context* : Context
- [In] *szDir* : Data
- [In] *uids* : 가
- [In] *uidCount* :
- [Out] *userBlob* :
- [In] *key* : [BS2_SetDataEncryptKey](#) .

BS_SDK_SUCCESS , 가

[BS2_GetUserSmallInfosFromDirWithKey](#)
[BS2_GetUserSmallDatasFromDirWithKey](#)
[BS2_GetUserSmallInfosExFromDirWithKey](#)
[BS2_GetUserSmallDatasExFromDirWithKey](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getusersmallinfosexfromdirwithkey

Last update: **2022/04/12 15:35**