

**BS2\_GetVoipConfig** ..... 1  
..... 1  
..... 1  
..... 1

## BS2\_GetVoipConfig

Voip            가

```
#include "BS_API.h"

int BS2_GetVoipConfig(void* context, uint32_t deviceId, BS2VoipConfig* config);
```

BS2VoipConfig

- [In] *context* : Context
- [In] *deviceId* :
- [In] *config* : Voip

BS\_SDK\_SUCCESS , 가

From:  
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:  
[https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2\\_getvoipconfig](https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_getvoipconfig)

Last update: **2017/06/28 11:27**