

BS2_ReleaseUsbContext 1

..... 1

..... 1

..... 1

..... 1

BS2_ReleaseUsbContext

[] [+ 2.5.0] [BS2_AllocateUsbContext](#) Context .
NULL .

```
#include "BS_API.h"

void BS2_ReleaseUsbContext(void* context);
```

- [In] *context* : USB Context

- [BS2_AllocateUsbContext](#)
- [BS2_GetUserDatabaseInfoFromDir](#)
- [BS2_GetUserListFromDir](#)
- [BS2_GetUserInfosFromDir](#)
- [BS2_GetUserDatasFromDir](#)
- [BS2_GetUserInfosExFromDir](#)
- [BS2_GetUserDatasExFromDir](#)
- [BS2_GetLogFromDir](#)
- [BS2_GetLogBlobFromDir](#)
- [BS2_GetFilteredLogFromDir](#)

From:
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_releaseusbcontext

Last update: **2022/04/12 14:04**