

BS2_ReleaseUsbContext 1
..... 1
..... 1
..... 1
..... 1

BS2_ReleaseUsbContext

BS2_AllocateUsbContext Context . NULL

```
#include "BS_API.h"  
  
void BS2_ReleaseUsbContext(void* context);
```

- [In] *context* : USB Context

- BS2_AllocateUsbContext
- BS2_GetUserDatabaseInfoFromDir
- BS2_GetUserListFromDir
- BS2_GetUserInfosFromDir
- BS2_GetUserDatasFromDir
- BS2_GetUserInfosExFromDir
- BS2_GetUserDatasExFromDir
- BS2_GetLogFromDir
- BS2_GetLogBlobFromDir
- BS2_GetFilteredLogFromDir

From:
<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:
https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_releaseusbcontext&rev=1540863283

Last update: **2018/10/30 10:34**