

BS2_SetDesFireCardConfigEx 1

..... 1

..... 1

..... 1

..... 1

BS2_SetDesFireCardConfigEx

[+ V2.6.4] DesFire

```
#include "BS_API.h"

int BS2_SetDesFireCardConfigEx(void* context, uint32_t deviceId,
BS2DesFireCardConfigEx* config);
```

BS2DesFireCardConfigEx

- [In] *context* : Context
- [In] *deviceId* :
- [In] *config* : DesFire

BS_SDK_SUCCESS , 가

BS2_GetDesFireCardConfigEx

From: <https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link: https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_setdesfirecardconfigex

Last update: **2020/02/17 16:50**