

BS2_SetDesFireCardConfigEx

.....

1

.....

1

.....

1

.....

1

.....

1

[Configuration API](#) > [BS2_SetDesFireCardConfigEx](#)

BS2_SetDesFireCardConfigEx

[+ V2.6.4]

DST

.

```
#include "BS_API.h"
```

```
int BS2_SetDesFireCardConfigEx(void* context, uint32_t deviceId,  
BS2DesFireCardConfigEx* config);
```

[BS2DesFireCardConfigEx](#)

- [In] *context* : Context
- [In] *deviceId* :
- [In] *config* : DesFire

BS_SDK_SUCCESS

, 가

.

[BS2_GetDesFireCardConfigEx](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_setdesfirecardconfigex&rev=1581925764

Last update: **2020/02/17 16:49**