

BS2_SetInterlockZone

.....

.....

.....

.....

.....

1

1

1

1

1

[Zone Control API](#) > [BS2_SetInterlockZone](#)

BS2_SetInterlockZone

```
#include "BS_API.h"

int BS2_SetInterlockZone(void* context, uint32_t deviceId,
BS2InterlockZoneBlob* zones, uint32_t zoneCount);
```

[BS2InterlockZoneBlob](#)

- [In] *context* : Context
- [In] *deviceId* :
- [In] *zones* : zone
- [In] *zoneCount* : zone

BS_SDK_SUCCESS , 가

[BS2_GetInterlockZone](#)
[BS2_GetInterlockZoneStatus](#)
[BS2_GetAllInterlockZoneStatus](#)
[BS2_SetInterlockZoneAlarm](#)
[BS2_RemoveInterlockZone](#)
[BS2_RemoveAllInterlockZone](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_setinterlockzone&rev=1520397376

Last update: **2018/03/07 13:36**