

BS2_SetSlaveExDevice 1
..... 1
..... 1
..... 1
..... 1

[Slave Control API](#) > [BS2_SetSlaveDevice](#)

BS2_SetSlaveExDevice

가 CoreStation

가 /

.

```
#include "BS_API.h"

int BS2_SetSlaveExDevice(void* context, uint32_t deviceId, uint32_t
channelPort, BS2Rs485SlaveDeviceEX* slaveDevices, uint32_t
slaveDeviceCount);
```

[BS2Rs485SlaveDevice](#)

- [In] *context* : Context
- [In] *deviceId* :
- [In] *channelPort* : channel port
- [In] *slaveDevices* : slave device
- [In] *slaveDeviceCount* : slave device

BS_SDK_SUCCESS

, 가

.

[BS2_GetSlaveExDevice](#)

From: <https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link: https://kb.supremainc.com/kbtest/doku.php?id=ko:bs2_setslaveexdevice

Last update: **2017/08/29 08:46**

