

2.6.0	1
	1
	1
	2
	4
	4
	5

2.6.0

2018-10-31

V2.5.0

가

,

,

V2.6.0

가

.

- USB (BioStation A2, FaceStation 2)
- Debugging API
-
- Global APB zone
-
-
- ,

1. USB

가

- BS2_AllocateUsbContext 가
- BS2_ReleaseUsbContext 가
- BS2_GetUserDatabaseInfoFromDir 가
- BS2_GetUserListFromDir 가
- BS2_GetUserInfosFromDir 가
- BS2_GetUserDatasFromDir 가
- BS2_GetUserInfosExFromDir 가
- BS2_GetUserDatasExFromDir 가
- BS2_GetLogFromDir 가
- BS2_GetLogBlobFromDir 가
- BS2_GetFilteredLogFromDir 가

2. SDK

가

- BS2_SetDebugExCallback 가

3.

가

- BS2_SetServerPort 가
- BS2_SetSSLServerPort 가

4. Global APB zone

가

- BS2_SetCheckGlobalAPBViolationHandler 가
- BS2_CheckGlobalAPBViolation 가

5. 가

- BS2_IsConnected 가

6. , 가

- BS2_IsAutoConnection 가
- BS2_SetAutoConnection 가

1. log , event mask

(mask)

- BS2_GetLogBlob
- BS2_GetLogBlobFromDir

2. ,
userMask가 0x3FF Invalid Parameter 가

- BS2_GetUserDatas
- BS2_GetUserDatasEx
- BS2_GetUserDatasFromDir
- BS2_GetUserDatasExFromDir

3. Multi context , context release crash 가
access violation

- BS2_AllocateContext
- BS2_ReleaseContext

4. SDK packet , buffer overflow crash 가

5. Entry , timeout

- BS2_RemoveAllUser

6. , userMask가 BS2_USER_MASK_ALL Not Supported 가

- BS2_GetSupportedConfigMask
- BS2_GetSupportedUserMask
- BS2_GetUserDatas
- BS2_GetUserDatasEx

7. Log data가 , crash가

- [BS2_GetLog](#)
- [BS2_GetFilteredLog](#)
- [BS2_GetLogFromDir](#)

8. RS485 multi packet packet

9. Linux SDK timer가 . (signal thread
)

10. Linux SDK signal handle memory dead-lock

11. Linux socket , socket close SOCK_CLOEXEC 가

12. Server matching lock/unlock

13. , (disconnected status) keep alive code

14. 가

- : (0 < door) AND (card data가), (0 < card) AND (door ID가)
- : (0 < door) AND (door ID가), (0 < card) AND (card data가)

- [BS2_SetIntrusionAlarmZone](#)

15. image log 가 timeout block

- [BS2_GetImageLog](#)
- [BS2_GetLogBlobFromDir](#)

16. data가 , allocation memory 가
zoneBlob NULL

- [BS2_GetIntrusionAlarmZone](#)

17. Socket 가 TCP 가

18. Entry , door ID가 65535 Invalid Parameter

- [BS2_SetDoor](#)

19. TCP handshake 가 가

20. FaceStation2 가

21. BS2 SearchDevicesCoreStation crash

22. BS2 EnrolUser face template, image

23. Not supported

- BS2_GetCardConfigEx
 - BS2_GetRS485ConfigEx

2018-04-15

- 2.5.0 Device SDK가 OpenSSL library
- 2.6.0 library
- OpenSSL library
- 2.6.0 OpenSSL 1.0.2n library
- OpenSSL 1.0.2n Windows library

- (BioLite N2, Xpass D2)
(DST)
 -
 -
 -
 -

1. BioLite N2, Xpass D2 . Xpass D2 slave

2. 가 가 2 가 .

- BS2_GetDstConfig 가
 - BS2_SetDstConfig 가
 - BS2DstConfig 가
 - BS2Event

3. CoreStation 가

- BS2_GetInterlockZone 가
- BS2_GetInterlockZoneStatus 가
- BS2_GetAllInterlockZoneStatus 가
- BS2_SetInterlockZone 가
- BS2_SetInterlockZoneAlarm 가
- BS2_RemoveInterlockZone 가
- BS2_RemoveAllInterlockZone 가
- BS2InterlockZoneBlob 가

4.

- BS2_GetDataEncryptKey 가
- BS2_SetDataEncryptKey 가
- BS2_RemoveDataEncryptKey 가

5. BS2_ResetConfigExceptNetInfo BS2_ResetConfig
가 가 .

- BS2_ResetConfigExceptNetInfo 가

6. BS2_GetDeviceInfo BS2_GetDeviceInfoEx
BS2SimpleDeviceInfoEx 가 .

BS2_GetDeviceInfo BS2SimpleDeviceInfoEx .

- BS2_GetDeviceInfoEx 가
- BS2SimpleDeviceInfoEx 가

1. Wiegand In/Out

Wiegand mode 2

- BS2WiegandConfig

2.

BS2SystemConfig secureTamper

BS2_SetSystemConfig BS2_GetSystemConfig

BS2_SetSystemConfig

- BS2SystemConfig

3. FaceStation2

slave FS2

FS2 BS2SimpleDeviceInfo.fingersupported 0 1

BS2SimpleDeviceInfo fingerSupported

- [BS2SimpleDeviceInfo](#)

From:

<https://kb.supremainc.com/kbtest/> - **BioStar 2 Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:release_note_260&rev=1540958735

Last update: **2018/10/31 13:05**