

USB Exported Control API 1

USB Exported Control API

Usb Exported

API

- **BS2_GetUserDatabaseInfoFromDir:** Usb Data (, , ,) 가 .
- **BS2_GetUserListFromDir:** Usb Data ID ID 가 .
- **BS2_GetUserInfosFromDir:** Usb Data ID 가 .
- **BS2_GetUserDatasFromDir:** Usb Data UserMask ID 가 .
- **BS2_GetUserInfosExFromDir:** Usb Data ID 가 . (Job, phrase v2.4)
- **BS2_GetUserDatasExFromDir:** Usb Data UserMask ID 가 . (Job, phrase v2.4)
- **BS2_GetLogFromDir:** Usb Data 가 .
- **BS2_GetLogBlobFromDir:** Usb Data EventMask 가 .
- **BS2_GetFilteredLogFromDir:** Usb Data 가 .

From:

<https://kb.supremainc.com/kbtest/> - **BioStar 2 Device SDK**

Permanent link:

https://kb.supremainc.com/kbtest/doku.php?id=ko:use_exported_control_api&rev=1540857729

Last update: **2018/10/30 09:02**