

USB Exported Control API 1

USB Exported Control API

USB Exported

API

- [BS2_AllocateUsbContext](#): USB Context
- [BS2_ReleaseUsbContext](#): USB Context
- [BS2_GetUserDatabaseInfoFromDir](#): USB Data (,) 가
- [BS2_GetUserListFromDir](#): USB Data ID 가
- [BS2_GetUserInfosFromDir](#): USB Data ID 가
- [BS2_GetUserDatasFromDir](#): USB Data UserMask ID 가
- [BS2_GetUserInfosExFromDir](#): USB Data ID 가 . (Job, phrase v2.4)
- [BS2_GetUserDatasExFromDir](#): USB Data UserMask ID 가 . (Job, phrase v2.4)
- [BS2_GetLogFromDir](#): USB Data 가
- [BS2_GetLogBlobFromDir](#): USB Data EventMask 가
- [BS2_GetFilteredLogFromDir](#): USB Data 가

From: <https://kb.supremainc.com/kbtest/> - **BioStar Device SDK**

Permanent link: https://kb.supremainc.com/kbtest/doku.php?id=ko:use_exported_control_api&rev=1540863426

Last update: **2018/10/30 10:37**